

Supercal 539

Compact thermal energy meter



Application

Electronic, battery-powered compact thermal energy meter intended to record heat consumption in autonomous heating systems or combined heating/cooling systems.

The **Supercal 539** compact thermal energy meter is used to measure heat energy or combined heating/cooling energy. The main area of application is a central heating or heating/cooling system that distributes heat or heat/cool to individual consumer and are billed based on the energy measured by the meter. With its two additional and optional pulse inputs (for the connection of water meters for example) the integration of a low cost system becomes a reality

Areas of applications:

- Urban heating stations
- The heating of one or several buildings in an urban
- Offices and administration buildings
- Malls
- Houses Low-energy

The compact thermal energy meter **Supercal 539** meets the requirements of European Standard EN 1434 (Class 3)

Functions

- Recording heat or heat/cool consumption by means of measuring the flow and temperature difference.
- Connecting two additional pulse inputs to the optical interface, M-Bus or radio system.
- Displaying consumption data:
 - Displaying 15 monthly energy and volume values
 - Displaying 15 monthly cooling energy
 - Displaying 15 monthly values of additional pulse input 1
 - Displaying 15 monthly values of additional pulse input 2
 - Displaying operating data
 - Self-monitoring with error display

Variants

Supercal 539 Plus

- Optical interface and two pulse inputs
- Optical interface, one pulse output for energy and two additional pulse inputs
- Optical interface, M-Bus and two additional pulse inputs
- Optical interface, bi-directional radio with two additional pulse inputs

Supercal 539 heating cooling: combined heating cooling meters

- Optical interface
- Optical interface, two pulse outputs for heating and cooling energy
- Optical interface and M-Bus
- Optical interface and bi-directional radio

Supercal 539 heating and cooling Plus

- Optical interface, two pulse outputs for heat and for cool energy and one additional pulse input.
- Optical interface. M-Bus and one additional pulse input.
- Optical interface, bi-directional radio with one additional pulse input.

Special version

- Energy unit: MWh, GJ
- Mounting in supply flow

Main feature

- Easy to operate and read.
- Non-volatile EEPROM memory.
- 15 monthly energy values for heat energy, volume, cooling energy and for the additional pulse inputs 1 and 2.
- The **Supercal 539** is suitable for all communication environments:
 - Optical interface, M-bus (as per EN 1434) and Radio.
 - Optional additional pulse inputs for low cost system integration.
 - Many years of reliable operation thanks to new contact flow sensor.
 - New energy-saving technology of the permanently connected Pt10'000Ω measuring unit.
 - The sensor mounting point is integrated into the flow sensor.
 - The Supercal 539 includes the functions necessary for self-monitoring, as well as for monitoring operating station.
 - Can be installed in supply or return flow

Design

The compact heat meter consists of a single jet flow sensor with magnet, a detection circuit for the magnet, an integrator and a temperature pair. The inlet fitting includes a filter to hold any larger impurities.

Flow sensor

The flow sensor complies with state-of-the-art technology. Thanks to the high quality standard, many years of operating reliability are guaranteed. The flow sensor operates in the dry, and the impeller wheel is equipped with a special hard metal bearing. As only the impeller wheel works in the wet area, problems that might be caused by impurities in the water are largely excluded. The sensor mounting point is integrated into the flow sensor.

Integrator

The integrator is equipped with a 7-digit LCD display and can be rotated through 360°. In standard metering operations the battery life of up to 6 years can be guaranteed.


Temperature sensor

The temperature sensor pair Pt10'000Ω is permanently connected to the measuring unit. The return flow sensor is built into the sensor mounting position in the flow sensor as standard. The supply flow sensor can be mounted directly or by means of sensor pockets




Display

The LCD display on the **Supercal 539** has a large, clear design making it easier to read



LCD display



Error messages

Error code	Description	Remedial action
Err 1	Water meter faulty	Return to manufacturer
Err 2	Temperature sensor faulty	Return to manufacturer
Err 3	Electronics faulty	Return to manufacturer

Technics

Measuring principle

The medium flowing through the system drives the impeller wheel and the rotational speed is scanned electronically using a magnet. The temperature difference in the supply and return flows is measured with a pair of platinum temperature sensors (Pt 10'000).

Energy calculation

The flow sensor records the flow and the pair of temperature sensors records every two minutes the supply and return flow temperatures. Using a microprocessor, the integrator calculates the temperature difference and then calculates the thermal energy, respectively the heating/cooling energy, consumed using the average flow and the heat coefficient.

Cooling energy consumption

The cooling energy is memorized in a separate register. The cooling energy is cumulated when the two following conditions are met:

- (Δt) Temperature difference $\geq -0.5K$
- Supply temperature $\leq 18^{\circ}C$

The temperature threshold value is parameterized at the factory at $18^{\circ}C$. The threshold value can be changed $1^{\circ}C$ -levels.

The cooling energy is updated every minute and has the same unit. When the supply temperature is lower than the return temperature, the signal will indicate the (–) negative symbol.

Non-volatile memory

The device parameters, as well as the cumulative values for energy and volume, operating hours and error type are stored in a non-volatile memory (EEPROM), and this information is not lost in the event of a power failure (e.g. changing batteries). Once a day and in the event of battery failure, the cumulative values are updated in the EEPROM.

Monthly values

On the first of the month the 15 monthly energy values for heat energy, volume, cool energy and for the additional pulse inputs 1 and 2 are stored in the integrator depending on the variant.

Pulse Inputs

The **Supercal 539** Plus offers in option the possibility of up to two additional pulse inputs for low cost system integration.


Communication options

The additional pulse inputs and outputs are equipped with a 1.5 m long cable. A splash proof distribution box (minimum IP54) is foreseen for the connection of the pulse inputs, outputs and of the M-Bus. The additional parameterization, other than the ex factory settings, of the Supercal 539 can be carried out with the free software Prog539 available from Sontex or its agents.

Technical data

Flow metering	Nominal flow q_p	0.6 m ³ /h	1.0 m ³ /h	1.5 m ³ /h	1.5 m ³ /h	2.5 m ³ /h
	Maximum flow q_s	1.2 m ³ /h	2.0 m ³ /h	3.0 m ³ /h	3.0 m ³ /h	5.0 m ³ /h
	Minimum flow q_i					
	Horizontal mounting	12 l/h	10 l/h	15 l/h	15 l/h	25 l/h
	Vertical mounting	24 l/h	20 l/h	30 l/h	30 l/h	50 l/h
	Starting point	< 3 l/h	< 3 l/h	< 5 l/h	< 5 l/h	< 8 l/h
	Nominal pressure	16 bar	16 bar	16 bar	16 bar	16 bar
	Pressure loss at q_p Δp	0.23 bar	0.23 bar	0.23 bar	0.23 bar	0.23 bar

Pressure lost curves



Metrological class

EN 1434 Class 3

Mounting	Nominal width DN	15 mm	15 mm	15 mm	20 mm	20 mm
	Connecting thread	G ¾ B	G ¾ B	G ¾ B	G 1 B	G 1 B
	Mounting length	110 mm	110 mm	110 mm	130 mm	130 mm
	Long-term operating temp.	90°C				
	Short-term operating temp.	110°C				

Temperature measurement

Temperature sensors	Pt10'000Ω
Integrator sensor	0 - 110°C
Temperature difference range Δt	3 - 75K
Minimum starting value	0.5K

Power supply Lithium battery, 3.6 V

Pulse outputs Open collector 1 Hz 500 ms

Pulse inputs	Power Supply	3.6V _{DC}
	R _{pull UP}	1 MΩ
	Pulse values	1, 2.5, 5, 10, 25, 50, 100, 250

Thermal energy meter	Environmental class	A
	Battery protection class	III
	Housing protection class	IP54 as per DIN VDE 0470, Part 1
	Permissible temperatures:	
	Transport and storage	-10 - 60°C (dry)
	Operation	5 - 55°C **
	Data memory	non-volatile
	Display	LCD, 7-digit
	Weight	0.8 kg

** The average annual permissible temperature with the radio option is 40°C


Installation instructions

- Local regulations regarding the use of thermal energy meters must be observed.
- The pipework must be flushed through before installing the meter.
- Both temperature sensors and all screw pipe joints must be fitted with seals.
- It is recommended to fit the thermal energy meter between two shut-off valves.
- The information given on the identification plate must be observed.
- It is essential to pay attention to the isolation instructions in order to avoid the accumulation of condensation in the integrator or a any capillary effect on the temperature sensor cable.

Operating instructions

Basically, the battery must be replaced in the event of re-certification or repair.

Dimension diagram and installation recommendations



Technical Support

For technical support contact your local Sontex agent or Sontex SA directly.

Hotline Sontex:

sontex@sontex.ch

+41 32 488 30 04



Conformity according to R&TTE 1999/5/CE

The detailed certificate of conformity can be found on our homepage

www.sontex.ch

Technical modifications subject to change without notice

Data Sheet Supercal 539 EN 09-06-2010

© Sontex SA 2007